


About Warnings

MARNING: A WARNING indicates a potential for property damage, personal injury, or death.

Dell™ Vostro™ 1220 Setup and Features Information

Front View



April 2009




Model: P03S series Type: P03S001

- 1 microphone (optional)
- 3 camera (optional)
- 5 media controls (volume, forward, reverse, stop, play, and mute)
- 7 security slot
- 9 USB connectors (2)
- 11 audio connectors (2)
- 13 wireless switch
- touch pad buttons (2)
- 17 keyboard
- 19 keyboard status lights

- 2 camera light (optional)
- 4 display
- 6 power button
- 8 optical device in media bay
- 10 fingerprint reader (optional)
- 12 power and battery charge status lights
- 14 speaker
- 16 touch pad
- 18 device status lights

Back View



- 1 ExpressCard slot
- 3 USB connector
- 5 VGA connector
- 7 phone connector

- 2 SD card reader slot
- 4 network connector
- 6 cooling vents
- 8 AC adapter connector

Quick Setup



WARNING: Before you begin any of the procedures in this section, read the safety information that shipped with your computer. For additional best practices information, see www.dell.com/regulatory_compliance.



WARNING: The AC adapter works with electrical outlets worldwide. However, power connectors and power strips vary among countries. Using an incompatible cable or improperly connecting the cable to the power strip or electrical outlet may cause fire or equipment damage.



CAUTION: When you disconnect the AC adapter cable from the computer, grasp the connector, not the cable itself, and pull firmly but gently to avoid damaging the cable. When you wrap the AC adapter cable, ensure that you follow the angle of the connector on the AC adapter to avoid damaging the cable.




CAUTION: Your computer ships with a plastic blank installed in the ExpressCard slot and SD card reader slot. Blanks protect unused slots from dust and other particles. Save the blank for use when no ExpressCard or media card is installed in the slot; blanks from other computers may not fit your computer.



NOTE: Some devices may not be included if you did not order them.


 Connect the AC adapter to the AC adapter connector on the portable computer and to the electrical outlet.



3 Connect USB devices, such as a mouse or keyboard (optional).



2 Connect the network cable (optional).



4 Open the computer display and press the power button to turn on the computer.





NOTE: It is recommended that you turn on and shut down your computer at least once before you install any cards or connect the computer to an external device, such as a printer.

Specifications



NOTE: Offerings may vary by region. The following specifications are only those required by law to ship with your computer. For more information regarding the configuration of your computer, click Start—Help and Support and select the option to view information about your computer.

System Information		
Chipset	Intel® GM45	
Processor		
Processors	Intel Celeron®, Intel Celeron Dual Core, or Intel Core™2 Duo	
Video		
Video type	integrated on system board	
Data bus	integrated video	
Video controller	Intel Extreme Graphics	
Video memory	up to 256 MB (shared)	
Memory		
Memory module connector	2 DIMM slots	
Memory module capacity	1 GB, 2 GB, or 4 GB	
Memory type	DDR2 800 MHz	
Minimum memory	1 GB	
Maximum memory	8 GB	
Battery		
Туре	4-cell and 6-cell	
Dimensions:		
Depth		
4-cell	46.50 mm (1.83 inches)	
6-cell	46.50 mm (1.83 inches)	
Height		
4-cell	35.85 mm (1.41 inches)	
6-cell	40.64 mm (1.60 inches)	

Battery (continued)

Voltage

4-cell 12 V (minimum), 17.7 V (maximum)

6-cell 9 V (minimum), 13.3 V (maximum)

Temperature range:

Operating 0° to 50°C (32° to 122°F)
Storage -20° to 65°C (4° to 149°F)

Coin-cell battery CR2032

AC Adapter

Type $65 \mathrm{W}$

Input voltage 100–240 VAC

Input current (maximum) 1.5 A

Input frequency 50–60 Hz

Output current:

65 W 4.34 A (maximum at 4 seconds pulse), 3.34 A (continuous)

Rated output voltage 19.5 VDC

Temperature range:

Operating 0° to 40°C (32° to 104°F)
Storage -40° to 70°C (-40° to 158°F)

Physical

Height:

with a CCFL panel 23.5–37.6 mm (0.93–1.48 inches)

with a WLED panel 23.5-36.6 mm (0.93–1.44 inches)

Width 294.0 mm (11.57 inches)

Depth 228.7 mm (9.00 inches)

Weight:

with a 4-cell battery, 1.52 kg (3.36 lbs)

128 GB SSD, WLED panel, and

no optical drive

Environmental

Temperature range:

Operating 0° to 35°C (32° to 95°F)

Storage -40° to 65°C (-40° to 149°F)

Relative humidity (maximum):

Operating 10% to 90% (noncondensing)

Storage 5% to 95% (noncondensing)

Finding More Information and Resources

If you need to:	See:
Find safety best practices information for your computer, review Warranty information, Terms and Conditions(U.S only), Safety instructions, Regulatory information, Ergonomics information, and End User License Agreement.	The safety and regulatory documents that shipped with your computer and the Regulatory Compliance Homepage at www.dell.com/regulatory_compliance.

Information in this document is subject to change without notice. © 2009 Dell Inc. All rights reserved. Printed in China. Printed on recycled paper.

Reproduction of these materials in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: *Dell*, the *DELL* logo, and *Vostro* are trademarks of Dell Inc.; *Intel* and *Celeron* are registered trademarks and *Core* is a trademark of Intel Corporation in the U.S. and other countries.

Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.